

The Instructions of Digital Clock

Time setting:

1. Long touch the switch three seconds, the first number flashes, then short touch the switch to set correct time.
2. Don't touch the switch when first number done, after three seconds the second number flashes, then short touch the switch to set correct time .
3. Don't touch the switch when second number done, after three seconds the third number flashes, then short touch the switch to set correct time .
4. Don't touch the switch when third number done, after three seconds the fourth number flashes, then short touch the switch to set correct time .
5. Don't touch the switch any more when all four numbers done , after three seconds the clock works .
6. If any problem , reset it again as above .

